


Clearing Memory on a PEM2®

This command file will clear all the accumulated data from the data logger. We do not recommend clearing the logger memory unless you are moving the logger to a new location. Back up the data on your logger to your computer before clearing the data.

1. The first step is to insert a blank flash drive into your computer. You'll be saving the command file to this flash drive; and then inserting it into the logger to apply the change.
2. Open your web browser to: https://eclimatenotebook.com/pem2_nl.php
3. Click on "Settings" Below where it says "PEM2 Hardware Support" (you will not need a username/ password to access this area).



PEM2® Hardware Support

Technical support for the Preservation Environment Monitor (PEM2®). This compact, highly accurate data logger is the easiest-to-use device of its kind on the market. One of the outstanding features of the PEM2 is its method of data retrieval: USB flash drive (commonly called a thumb drive or USB key) inserted directly into the logger.



4. Enter the serial number for the logger in the first text field (in the format P2_XXXXX).



The serial number is NOT required, and if a serial number is entered, the command file will ONLY work on that datalogger.

5. Find the Checkbox labeled "Clear Logger Memory" and click to select it.
6. Click on the "Generate" button at the bottom of the page.
7. A popup will appear prompting you to confirm that you wish to delete all of the data from the data logger. This action cannot be undone. This will create a file called command.pm2 (or P2_XXXXX.pm2, such as P2_01234.pm2, if you entered a serial number) – it will either automatically be saved to your "Downloads" folder, or you will be prompted to select a Save In location; this will depend on your web browser's settings.
8. Once the file is saved to the flash drive, eject it from your computer and then insert it into the PEM2 logger. Once the hourglass goes away, remove the flash drive. Once the hourglass goes away, remove the flash drive. The new settings are applied.